



HIVAMI

# HIVAMI WATCH CUBE 760 PRO

## Manual



Thank you for choosing Hivami Products. you can learn your product easily by this manual. Let's check it.



- 01 WHATS IN BOX
- 02 BUTTONS
- 03 SCREEN SHORTCUT FUNCTIONS
- 04 PAIRING THE WATCH
- 05 BLUETOOTH CALL, HISTORY CALLS
- 06 DROP-DOWN MENU
- 07 APP NOTIFICATION & MESSAGE
- 08 FREQUENTLY USED CONTACTS
- 09 FUNCTIONS
- 10 FAQ
- 11 WARRENTLY

## 01 WHAT'S IN BOX

---



SMART WATCH x 1  
SILICONE STRAP x 1  
METAL STRAP x 1




WIRELESS CHARGER



MANUAL

## 02 ABOUT THE WATCH

---



### **Up button:**


Short press to light up or turn off the screen; one press to go back the dial interface; long press to reactivate the watch. double-press for changing the arrangements of the menu.

### **Button down:**

Short press to enter multi-sport mode. In addition, when the watch is in the off-screen state, you can light up the screen by pressing any buttons.

### **Rotate button:**


Twirling the key for changing watch face or scrolling screen.

**Charging:**

Wireless charging, as shown in the picture. Connect the watch's charging cable to a power 1A adapter or a computer's USB port. When charging starts, the watch screen displays the charging progress.

**Note:**

1. Please use the charging base that comes with the watch. Make sure that the charging base is dry before charging.
2. Please use a 1A power adapter

**Assembling the Watch Strap:**

Please refer to the illustrations to disassemble or assemble the watch strap. Once the strap is assembled, pull the strap properly to ensure it is installed successfully.

## 03 SCREEN SHORTCUT FUNCTIONS

---

1. Swipe to the left till you find the "+" icon, click the icon to add part of the functions in the shortcut.
2. Scroll down the screen when the watch is in the dial interface, you can find Bluetooth connection status, time, power, brightness adjustment and other functions.
3. Swipe to the right when the watch is in the dial interface, you can find time/date/week/the latest message (enter to view multiple messages)/some of the recently used menu functions, and turn on or off audio Bluetooth for calls.
4. Swipe up the screen when the watch is in the dial interface to enter the menu interface, and scroll up and down to find the corresponding function.
5. Long press the watch face interface and swipe to right or left to switch the watch face, select one of them and set it with one-click.
6. Double tap on screen to activate voice assistant.



## 04 PAIRING THE WATCH

---



- 4.1. Charge smartwatch fully almost 2 to 3 hours
- 4.2. At phone turn Bluetooth, location and data on
- 4.3. Use your mobile phone to scan the QR code to download and install the app, or search for the app in the Google Play Store or Apple App Store and then download and install the latest version of the app
- 4.4. Open the app, register an account and log in, also you can enter anonymously.

### **Connection status :**

#### **Unconnected to the APP state**



After the watch is turned on, the Bluetooth will be in the state of being searched. After open the APK/APP, go to Devices > Add Device > click to start searching, select and click the corresponding watch device name, and the watch will be successfully bound to the app.

#### **Connected to the APP state**



Watch time synchronization: the time shown at the smartwatch and your mobile phone will be synchronized after the smartwatch is bound to the APP successfully.

## **Binding the audio/calling Bluetooth :**

When the smartwatch is in the dial interface, you can find the audio/calling Bluetooth icon, and click it to turn it on, then go to the Bluetooth settings of your mobile phone and click the name of the audio/calling Bluetooth of the smartwatch to bind it.


## **Unbind device :**

In the "Device" column of WearPro, scroll down to the bottom to tap "Unbind"; for ios users also go to the Bluetooth settings of the mobile phone, select the Bluetooth name of the smart watch, and click "Ignore this device".



## 05 BLUETOOTH CALL, HISTORY CALL

1. Swipe to the left when the watch is in the watch interface, click the calling icon to turn on/off the calling Bluetooth. Turn on the calling Bluetooth, you will find the name of the calling Bluetooth, then go to the Bluetooth settings of your mobile phone, and bind the Bluetooth in the name of the calling Bluetooth of your watch. You can use the watch to make phone calls when they are successfully bound.



(step 1)

(step 2)




(step 3)

(step 4)

2. Call records, which can save the records of incoming and dialed calls. (It can save more than 50 call records, and it will be automatically overwritten when 128 records are full. Click any call record to call back)

3. Dial the keyboard, you can enter the phone number to make a call.





### NOTE:

After activating Bluetooth Call, you can manually set the access or non-access of sound for conversation and music playback. To do this, enter the Bluetooth settings from the phone's Bluetooth then by holding on the watch's Bluetooth name you can make the desired settings.

## 06 DROP-DOWN MENU

---

Scroll down the screen when the watch is in the dial interface to enter the drop-down menu interface.

**1. Bluetooth connection status,time, power left.**

**2. About:** where you can check the firmware version of watch and the address of the Bluetooth

**3. Setting:** where you can enter it to set part of the functions.

**4. Brightness adjustment:** where you can adjust the brightness of the screen.

**5. Time setting:** the time can be manually calibrated.

**6. Wake up the screen with hand lifting:** You can decide whether the watch will turn on the screen when you lift the wrist wearing a smartwatch.

**7. Wake up the screen with touching:** You can set whether the watch can be woken with touching when the screen is off .

**8. SOS emergency call setting:** You can set a quick call number. When the audio Bluetooth of the watch is connected to the mobile phone, long press the button when the watch is on the dial interface, and the emergency number will be called from the watch.

**9. My QR code:** QR codes can be stored on the phone and synchronized to the watch, such as business card, payment code, etc. Connect the watch to the APP, find My QR Code in the APP, select WeChat/QQ/Alipay and other "Receive money QR code" to sync to the watch (Please follow the instructions of the app to operate the function).

**10. Mute switch:** If this switch is set on mute, the watch will not play any sound.

## **07 APP NOTIFICATION & MESSAGE**

---

When the watch is successfully bound to the app, and you approve notifications of corresponding apps in your mobile phone system, and switch on these apps or callings notifications functions on your watch, the notifications on your mobile phone can synchronize to your watch.

### **7.1. Incoming call notification:**

Turn on the incoming call reminder in the app. When the phone has a incoming call, the watch will light up or vibrate.

### **7.2. SMS notification:**

Enable the SMS notification in the app. When one or more SMS messages are received on the mobile phone, the watch will receive one or more SMS reminders at the same time.

### **7.3. Other application message notifications:**

Turn on the corresponding application message notification in the app, such as WeChat, QQ, Outlook, Facebook and other applications. When the mobile phone receives one/multiple application message notifications, the watch will receive one/multiple corresponding message reminders at the same time.

## **08 FREQUENTLY USED CONTACTS**

---

The watch binds to the app, and you allow the watch to access to the phone book of your mobile phone, then you can synchronize you contacts of your mobile phone to the smartwatch.

## **09 FUNCTIONS**

---

### **9.1. Fitness data**

Fitness data is turned on by default. When you enter the fitness data interface, scroll up the screen, the smartwatch will display the current data of steps, distance, and calories. The data will be wiped out at 00:00 every day in the morning.

**9.2. Sports modes:** (walking, running, cycling, rope skipping, badminton, basketball, football)

9.2.1. Select the corresponding exercise mode, click the "Start" button on the screen to start the exercise; click the "Start" button again to pause the recording of the exercise; click the "End" button to end the recording, and save to the data.

9.2.2. The data can only be saved when the recording of the exercise is more than 1 minute; If the recording time is less than 1 minute, the smartwatch will remind you that the data is too little to be saved.

### **9.3. Heart rate**

After you wearing the smartwatch correctly, you can measure heart rate when you enter the heart rate function. If you don't wear the smartwatch properly, it will remind you to wear firmly for the measurement.

### **9.4. ECG**

After you wearing the smartwatch correctly, and enter the ECG function(you need to turn on the ECG interface in the app, you can have single measurement at a time. The data of ECG will be saved in the mobile phone. This function should be used with the app.

**(Attention : not replacement for medical device.)**

### **9.5. Remote control music**

Bind the smartwatch to the app WearPro, you can control the music to start/pause/play previous song/play next song of your phone.Bind the audio/calling Bluetooth of the smartwatch also, the music will be broadcast on the smartwatch.

### **9.6. Sleep**

Sleep monitoring time period: from 18:00 at night to 10:00 the next day, the data will be generated by the watch. After connecting to the APP, the sleep data on the watch can be synchronized to the APP for you to check.

### **9.7. Stopwatch**

Click the stopwatch to enter the timing interface, and you can record the time once.

### **9.8. Weather**

After the smartwatch is connected to the app and the data is synchronized, tap Weather on the watch to display the weather information for the day.

## **9.9. Find mobile phone**

After the watch is bound to the app WearPro, tap this function to find the mobile phone, and the mobile phone will vibrate or emit a ringtone.

## **9.10. Meteorology**

Click on "Meteorology" on the watch to display the ultraviolet (UV) and air pressure conditions of the day.

## **9.11. Massager**

Tap the green button to start the massage, and the watch is in a vibrating state, tap the red button to end the massage state.

## **9.12. Menu style**

There are a variety of menu styles for users to choose.

## **9.13. Settings**

9.13.1. You can select the watch language on the settings of the watch, or the watch language can be synchronized with your mobile phone language after the watch successfully binds to the APP.

9.13.2. Switch the watch face, swipe to the right to view the next watch face, select a watch face, and click it to set the watch face.

9.13.3. Screen-on and screen-off: You can set the bedside lamp mode, styles of screen-off, and screen time.

9.13.4. Vibration intensity; set reminder vibration intensity.

9.13.5. Password; a 4-digit password can be set (if you forget the password, please enter 8762 to decrypt the previous password).

9.13.6. Restore factory settings; click Y to enable the factory reset, and click X to cancel the factory reset.

## **9.14. Unbind the APP Bluetooth connection**

9.14.1 Unbinding APP Bluetooth on Android system:

In the "Device" column of WearPro, scroll down to the bottom to tap "Unbind";

9.14.2 Unbinding APP Bluetooth on IOS system:

In the "Device" column of WearPro, scroll down to the bottom to tap "Unbind"; then go to the Bluetooth settings of the mobile phone, select the Bluetooth name of the smart watch, and click "Ignore this device"

After unbinding with Bluetooth on the APP, the green color of the Bluetooth icon of the watch is off, but the blue color outside the icon is still on.

## **9.15. Unbind the audio Bluetooth**

To unbind the audio Bluetooth, find the audio Bluetooth name of the smartwatch in the Bluetooth settings of the mobile phone, and click "Ignore this device" to unbind all Bluetooth connections with the watch. After all operations are completed, the Bluetooth icon of the watch will return to gray which means no connection.

## **9.16. Find Watch**

After the smartwatch is bound to the APP, you click "Find Watch" in the APP, the smartwatch will light up and vibrate for once.

## **9.17. Camera**

Click "camera" in the app WearPro to wake up the camera mode of the watch, click the camera button on the watch to take photos, and the photos will be automatically saved to the phone album.

## **9.18. Data synchronization**

After the watch is successfully bound to the application, the data in the smartwatch can be synchronized to the application.

### **9.19. Tilt to wake the screen**

Wear the smartwatch correctly on your wrist (left/right hand). when you switch on the feature, you can light up the screen when you raise up your wrist.

### **9.20. Do not disturb mode**

In the APP, tap "Device" > "More" > "Do not disturb mode", set the start to end time, such as 12:00 to 14:00, then you won't receive phone calls and apps notifications on the watch during this period.

### **9.21. Daily alarm clock**

9.21.1. In the APP in the APP Device>More, set the start and the end time, the alarm can be set for only once or repeatedly (weekly), and the alarm can be turned on/off.

9.21.2. You can also set the alarm clock on the watch. You can set it for only once or repeatedly (weekly), and you can turn on/off the alarm clock.

### **9.22. Sedentary reminder**

Set the start and the end time of the sedentary reminder, and the time interval (minutes) in the APP. You can set the reminder for once or to repeat regularly by entering the repeating setting. When the sedentary time is reached, the watch will vibrate and display a sedentary icon on the screen.

### **9.23. Drink water reminder**

Set the reminder frequency (minutes) and the time period of the start and the end in a day in the APP. You can set the reminder for once or to repeat regularly by entering the repeating setting and selecting the date (week) of the water reminder. When the time of drink water reminder is reached, the watch will vibrate and there will be a water icon on the screen.

## **9.24. Dial push**

### **9.24.1. Push an existing watch face**

Bind the watch and the app, open the app, tap Device > Watch face push, the watch will restart and bind the APP automatically after the synchronization of the watch face.

### **9.24.2. Customize the watch face**

Bind the watch and the app, open the app, tap Device > Watch face push, the first several watch faces marked with "custom watch faces" are customizable. The watch will restart and bind the APP automatically after the synchronization of the watch face.

## **9.25. Firmware version**

The version of the watch is displayed on "Firmware upgrade" in the column of "Device", and users can decide to whether upgrade the firmware version.

## **9.26. Unbind**

In the "Device" column of WearPro, scroll down to the "Unbind" and click to unbind the APP. The iSO users need to go to the Bluetooth settings of the phone, select the Bluetooth name of the smart watch, and click "Forget this device". The "About" of the watch has an "Unbind" button, click it to unbind or do it in the APP. For the safety of users' data, the watch will implement a factory reset after that.

## **9.27. Time setting**

When the watch is not connected to the APP, you can manually calibrate the time on the watch.

## **9.28. Countdown**

You can set a time period in the watch to count down.

## **9.29. Ringtone settings**

The watch comes with inbuilt ringtones, and you can set the source of the ringtone and choose one of the ringtones in this setting.

If you select "Default", the ringtone comes from the phone

If you select "None", the watch will be silent.



## 10 FAQ

---

### **Frequently asked questions and answers**

**\*Please avoid exposing the device to extreme temperatures that are too cold or too hot for a long time, which may cause permanent damage.**

#### **\*Why can't I take a hot bath with my watch?**

The temperature of the bath water is relatively changed, it will produce a lot of water vapor, and the water vapor is in the gas phase, and its molecular radius is small, and it is easy to seep into the gap of the watch case. The internal circuit of the watch is short-circuited, which damages the circuit board of the watch and damages the watch.

#### **\*No power on, no charging**

If you receive the goods and the watch does not turn on, it may be caused by a collision during the transportation of the watch and the battery Seiko board has been protected, so plug in the charging cable to activate it. If the battery is too low or the watch does not turn on after a long period of time, please plug in the data cable and charge it for more than half an hour to activate.

#### **How can I have the battery life extended?**

The simplest way to do so is deactivating notifications or limiting them. Also auto screen light, dimming the screen and limiting connections like Wi-Fi or NFC can extend the battery life, too. An exclusive feature that is available in most smart watches is the Bluetooth call or direct call with the smart watch; this feature can consume the battery up. Be noted that this feature is not useful in public and noisy places, so you could activate it in urgent needs only.

### **Is the Smartwatch repairable?**

In most cases with malfunctioning of the device, you will be needed to purchase a new one. But if the product is a well-known brand purchased from reputable store, you will be able to use the warranty. If you have just noticed minor malfunctions in the device, it would be better to stop it from becoming a major one to prevent any greater expense.

### **In case of malfunction or loss, is any accessory available for the device?**

As you purchase your good from reputable store, it is highly recommended to purchase the accessories from online store to have guard cases, cables, adaptor and standard band of your device in a short time. Hivami has supplied most of the products with their accessories and parts.

## **11 WARRENTLY**

---

11.1. No warranty is provided as follows:

11.2. Failure caused by unauthorized disassembly or modification of the watch.

11.3. Failure caused by accidental fall during use.

11.4. All man-made damages or the third party's fault, or misuses (such as: water in the device, cracking by external force, scratches on the case, damage, etc.) are not covered in the warranty.

11.5. When requesting the warranty service, please provide a warranty card with the date of purchase and the stamp of the place of purchase on it.

11.6. When the user needs the device repaired, please take the device to our company or our company's dealership.

11.7. All functions of the device please refer to the actual product.